

FAULT TRACING

Before having a look through the engine, or attempting to dismantle it, always remember the following points:

When complaints are made about excessive fuel or oil consumption or lack of power, the first course is to find out under what conditions the vehicle is operated.

Question the driver about the nature of operation and about his manner of driving.

Also ask him to take you for a short run and observe his driving habits.

Rapid acceleration, racing the engine, high idling speed setting, and high cruising speeds all produce high fuel and oil consumption.

High oil consumption may be the result of too high an oil level.

The oil need not be replenished until the level has fallen to, or slightly above, the lower mark on the dipstick. It must never be allowed to drop below this mark.

Various instruments can be used for fault tracing and the instructions for use with each individual instrument should be carefully followed.

FAULT

REASON	REMEDY
Engine will not start	
<p>No fuel in carburetor</p> <p>No fuel in tank. Fuel pump diaphragm faulty. Leaking fuel pump valve. Fuel filter clogged. Leaking filter gasket. Fuel line clogged or leaky. Fuel tank vent hole stopped.</p>	<p>Fill fuel. Replace diaphragm. Replace defective valve. Dismantle and clean. Replace defective gasket. Flush out, trace and repair leak. Remove filler cap and clean.</p>
<p>Ignition system</p> <p>Spark plugs fouled, breaker point gap too large. Distributor defective. Battery run down.</p> <p>Condenser defective. Ignition coil defective. Damaged suppresser on spark plug.</p>	<p>Clean plugs, adjust gap, and test or replace plugs. Inspect, adjust. Check acid specific gravity and recharge if below 1.230. Test and replace if necessary. Test and replace if necessary. Replace.</p>
<p>Carburetor</p> <p>Choke flap binding. Fuel inlet valve or jets clogged. Defective gaskets. Air cleaner clogged.</p>	<p>Check that spring can close flap. Dismantle and clean carburetor. Replace with new gaskets. Clean it.</p>
<p>Low compression</p> <p>Cylinders, pistons or piston rings worn or stuck. Valves sticky . Cylinder head gasket defective.</p>	<p>Measure compression in all cylinders. Replace gasket.</p>

Difficult starting**Carburetor**

Incorrect fuel level in float bowl.
 Faulty float or valve.
 Clogged jets or passages.
 Flooding.

Verify cause, and effect adjustments.
 Dismantle and clean carburetor.
 Check needle valve and float. Clean or replace.

Oil

Thick or dirty oil.

Change oil.

Engine will not idle**Carburetor**

Incorrect fuel level in float bowl.
 Leaky float valve.
 Idling jet clogged.
 Wrong idle setting, idling screw or idling air screw setting.
 Defective gasket between carburetor and intake manifold.
 Leak at vacuum pipe connection.

Check, adjust.
 Clean jet.
 Carry out all idle adjustments.
 Replace gasket.
 Examine and repair.

Difficult starting (cold)

Choke flap not closed.

Remove air cleaner. Pull out knob on instrument panel to see if spring on choke spindle can close choke flap. Clean spindle and bearings, replace spring if necessary.

Rapid idling faultily adjusted.

Check setting, see "Adjusting rapid idling".

Excessive fuel consumption**Leakage**

Damaged fuel tank.
 Damaged fuel line.
 Leaky nipples and fittings.

Check for leaks, and repair.
 Replace damaged part.
 Tighten or replace defective part.

Ignition system

Defective ignition timing.
 Defective distributor.
 Defective ignition coil.
 Defective condenser.

Adjust ignition timing.
 Test and adjust.
 Test and replace if irreparable.
 Test and replace if necessary.

Carburetor

Mixture too rich.
 Air cleaner clogged.
 Economiser valve diaphragm or washers leaking.

Adjust settings. See below under "Fuel system".
 Clean thoroughly.
 Check that screws are tight. Replace washers or diaphragm.

Acceleration pump outlet valve ball jammed in upper position.

Remove valve and clean in alcohol or replace.

Excessive oil consumption

Leakage

Leaky oil pan gasket.
Leaky gasket between fuel pump and cylinder block.
Damaged oilslinger or felt washer in timing gear casing.
Defective sealing at rear main bearing.
Blocked drain hole at front or rear seal.
Defective gasket on oil cleaner.

Replace gasket.

Replace gasket.

Replace damaged parts.

Replace felt seal.

Check holes are open when replacing felt seals.

Replace gasket after checking.

Cylinders, pistons, piston rings

Worn cylinders, pistons or piston rings.

Check compression pressure in all cylinders; see "Compression Test".

Gummed or broken gudgeon pins.

Replace.

Worn valve guides.

Replace.

Low oil pressure

Oil pressure gauge

Pressure gauge damaged.
Clogged oil line to gauge.

Test gauge, replace faulty gauge.

Clean, replace if damaged.

Relief valve

Plunger stuck in open position.
Broken or weak spring.
Plunger worn.

Dismantle valve and replace plunger.

Replace spring.

Replace with new plunger.

Oil strainer and pipe

Strainer clogged up.
Leak in outlet pipe.

Clean.

Examine.

Oil pump

Worn gears.

Replace pump.

Main and connecting rod bearings

Bearings damaged or worn.

Replace bearings. If crankshaft damaged, regrind journals.

Oil cleaner

Element blocked.
Faulty bypass valve in cleaner.

Fit new element.

Replace valve.

Engine does not deliver full power

Low compression

Worn cylinders, pistons, piston pins.
Valves sticking.

Check compression in all cylinders.
Grind valves.

Fuel tank, lines and pump

Incorrect fuel .
Leaking valves in fuel pump.
Filter clogged.

Drain tank and clean.
Replace valves.
Dismantle and clean filter.

Carburetor

Air cleaner blocked.
Jets clogged.
Carburetor adjustment disturbed.

Dismantle filter and flush clean.
Clean jets.
Clean and adjust carburetor.

Engine overheats

Coolant

Insufficient water in cooling system.

Add water.

Water pump and thermostat

Fan belts slips.
Pump impeller damaged.
Thermostat defective.

Tighten belt.
Replace impeller.
Replace thermostat.

Radiator, coolant hoses and passages

Radiator stopped.
Hoses or passages stopped by dirt and sludge.
Water distributor pipe clogged.

Clean.
See under "Stopped radiator".
Dismantle and clean pipe.

Ignition timing and carburetion

Wrong ignition timing.
Too lean fuel mixture.

Adjust ignition timing.
Clean and adjust carburetor.

Engine misses

Fuel tank, lines and pump

Incorrect fuel, or water in fuel.
Fuel line partly obstructed.
Fuel pump defective.

Drain tank, flush out, and fill new fuel.
Examine and flush.
Verify cause and replace damaged part.

Distributor

Poor contact in coil terminal.
Loose contact in primary circuit.
Open or short-circuit in primary circuit.
Defective ignition cables.

Examine and adjust.
Examine and adjust.
Trace fault and effect corrections.
Clean connections. Replace cables if insulation poor.
Check and adjust.
Replace.

Faulty contact breaker gap.
Burned breaker points.

Carburetor floods or leaks

Float system

Dirt in inlet valve.
 Valve or valve seat worn.
 Float damaged.
 Fuel pump pressure too high.
 Fuel line leakage at fitting.
 Fuel level faulty through wrong washer thickness.

Clean valve and seat.
 Replace damaged parts.
 Repair float.
 Check pressure.
 Replace defective line or fitting.
 Check correct washer fitted between float valve and cover.

Jerky running when accelerating suddenly

Acceleration system

Leaking inlet valve.
 Strainer clogged.
 Plunger binds - impurities in barrel.
 Acceleration jet clogged.

Replace valve.
 Clean strainer.
 Clean acceleration pump.
 Clean acceleration jet.

Uneven idling

Idling system

Idling air screw wrongly set.
 Dirt in idling jet.
 Idle port partly blocked.

Adjust.
 Remove and clean.
 Remove carburetor, clean port.

Air leakage

Air leak at carburetor gaskets.
 Air leak at vacuum pipe connection.

Replace defective gasket or tighten bolts.
 Adjust.