## ANNUAL SERVICE or 10,000 miles

**\$80** 1998-99

	<b>VOLVO</b>
OWNERS NAME	Mr WILDSMITH

		-			MILEA	GE 14958	
					Key		
					í	cked/Completed 💋 Adjuste ds Attention 🛣 Not App	
Annual service or 10,000 miles			Front wheel bearings	Check/rep	ort $\square$	Timing belt (diesel)	Check/adjus
VEHICLE ON FLOOR	10 10 11 11 11 11 11		Air filter (diesel)	•	w 🖂	Auxiliary drive belt (every 80,000 miles or 6	
Wash/wipe system	Chask/renert		Air filter housing/pipes/hoses (diesel)	Check/cle	an 🔲	whichever occurs first - check date/mileage	
Exterior lighting system	Check/report Check/report	吕	Diesel fuel filter	Rene	w 🔲	Diesel injection pump drive belt	Check/adjus
VEHICLE FULLY RAISED	Checkreport	9	Crankcase ventilation (petrol)	Check/cle	an 🔲	Spark plugs	Renev
	0. 14	$\overline{}$	Timing belt (diesel)	Check/adju	ıst 🔲	Diesel dynamic pump timing	Check/adjus
Engine oil leaks Engine oil	Check/report		F		_	Additional at 130,000 mile service	
Engine oil filter	Drain/refill		The state of the s	,	ew 🔲	1 -	Observed
Clutch hydraulic system	Renew			Check/adju	_	Steering/suspension	Check/repor
Gearbox oil leaks	Check/report	=	Diesel dynamic pump timing	Check/adju	st 📙	Exhaust system/mountings Front wheel bearings	Check/repor
Gearbox oil (only in event of leakage)	Check/report , Check/top-up	=	Additional at 70,000 mile service				Check/repor
Auto transmission oil leaks	Check/report	=	Steering/suspension	Check/repo	ort 🔲	Additional at 140,000 mile service	
Auto transmission inhibitor switch	Check	=	Exhaust system/mountings	Check/repo		Steering/suspension	Check/repor
Drive shafts	Check/report	=	Front wheel bearings	Check/repo	ort 🔲	Exhaust system/mountings	Check/repor
Brake pipes/hoses condition	Check/report	=	Additional at 80,000 mile service			Front wheel bearings	Check/repor
Fuel system leakage	Check/report	=	Steering/suspension	Check/repo	v4 [	Timing belt (diesel)	Check/adjus
VEHICLE HALF RAISED	Oncorreport		Exhaust system/mountings	Check/repo	=	Diesel injection pump drive belt	Check/adjust
Brake pads/discs	Check/report	ىد	Front wheel bearings	Check/repo	_	Diesel dynamic pump timing	Check/adjust
landbrake cables/linkages	Check/report	_	Air filter (petrol)	Rene	_	Additional at 150,000 mile service	
landbrake cables/linkages	Adjust		Air filter housing/pipes/hoses (petrol)	Check/clea	=		L
Brake hydraulic system			Timing belt/tensioner (diesel)	Rene		Auto transmission oil (adverse condition	,
yre condition	Check/report	_	Auxiliary drive belt (every 80,000 miles or 6	vears	" □	Steering/suspension	Check/repor
•	Check/report	<u></u>	whichever occurs first - check date/mileage	decal) Rene	w 🔲	Exhaust system/mountings	Check/repor
UNDER BONNET OPERATIONS	o	_	Diesel injection pump drive belt/tension		=	Front wheel bearings	Check/repor
	Clean/r <del>e-greas</del> e [	_	Spark plugs	Rene	_	Air filter (diesel)	Renew
lattery electrolyte level	Check/top-up		Additional at 90,000 mile service			Air filter housing/pipes/hoses (diesel)	Check/clear
lattery security	Check [		Steering/suspension	Check/repo	<i></i>	Diesel fuel filter	Renew
luid reservoir levels	Check/top-up [		- Exhaust system/mountings	Check/repo		Crankcase ventilation (petrol)	Check/clear
Coolant level/anti-freeze strength	Check/adjust [		Front wheel bearings		=	Additional at 160,000 mile service	
coolant hoses	Check/report [		Air filter (diesel)	Check/repo	=	Steering/suspension	Chaplifornad
cooling system	Pressure test [	니	Air filter housing/pipes/hoses (diesel)	Rene	=	Exhaust system/mountings	Check/report
uto transmission level only in event of leakage)	Check/ton +	لت	Diesel fuel filter	Check/clea Rene	=	Front wheel bearings	Check/report
ollen filter (if fitted)	Renew [		Crankcase ventilation (petrol)	Check/clea	=	Air filter (petrol)	Check/report Renew
iesel fuel filter	Drain [		Additional at 100,000 mile service	Official		Air filter housing/pipes/hoses (petrol)	Check/clean
FINAL ITEMS CHECK	Diani L	<b>-</b> '				Timing belt/tensioner (diesel)	Renew
ervice reminder lamp (SRL)	Doost [	٦,	Auto transmission oil (adverse condition			Auxiliary drive belt (every 80,000 miles or 6	neare
, , ,	Reset L Check/lubricate		Steering/suspension	Check/repo		whichever occurs first - check date/mileage of	lecal) Renew
ROAD TEST VEHICLE	Shecklublicate [	-	Exhaust system/mountings	Check/repo	_	Diesel injection pump drive belt/tensione	
		_	Front wheel bearings	Check/repo		Spark plugs	Renew
s per separate sheet	Check/report E	4	Timing belt (diesel)	Check/adjus	it 📙		
Additional at 20,000 mile service	يستوسا		Timing belt/tensioner (petrol every 110,000 miles whichever occurs first - check date/mileage of	or 10 years	, <b>—</b>	Additional at 170,000 mile service	
ming belt (diesel)	Check/adjust [		Diesel injection pump drive belt	Check/adjus	=	Steering/suspension	Check/report
iesel injection pump drive bett	Check/adjust [	$\exists$	Diesel dynamic pump timing	Check/adjus	=	Exhaust system/mountings	Check/report
iesel dynamic pump timing	Check/adjust [	٦ĺ	_	Checkaujus		Front wheel bearings	Check/report
Additional at 30,000 mile service			Additional at 110,000 mile service			Additional at 180,000 mile service	
r filter (diesel)	Baraw [	4	Steering/suspension	Check/repor	t 🔲		
r filter housing/pipes/hoses (diesel)	Renew [	≓۱	Exhaust system/mountings	Check/repor	t 🔲	Carry out 60,000 mile service	
esel fuel filter	Check/clean	41	Petrol fuel filter	Renev		Additional at 190,000 mile service	
	Renew	_	Front wheel bearings	Check/repor	t 🔲	Steering/suspension	Check/report
Additional at 40,000 mile service			Cooling system thermostat (6 cyl. engin	e) Renev	<i>'</i> 🗆		Check/report
r filter (petrol)	Renew [		Timing belt/tensioner (petrol every 110,000 miles	or 10 years			Check/report
r filter housing/pipes/hoses (petrol)	Check/clean [		whichever occurs first - check date/mileage d	lecal) Renev	′⊔∣		
ming belt (diesel)	Check/adjust	$\Box \parallel$	Additional at 120,000 mile service			Additional at 200,000 mile service	
esel injection pump drive belt	Check/adjust	]	Steering/suspension	Check/repor	ı 🗆 İ	Carry out 100,000 mile service including	:-
park plugs	Renew [			Check/repor		Air filter (petrol)	Renew
esel dynamic pump timing	Check/adjust	]	Front wheel bearings	Check/repor		Air filter housing/pipes/hoses (petrol)	Check/clean
Additional at 50,000 mile service		<b>.</b>	Air filter (petrol)	Renew	= 1	Spark plugs	Renew
ito transmission oil (adverse condition	ne) Drain/rofill C	┩╽.	Air filter (diesel)	Renew		Additional every 2 years	
	io) Diamireilli [	╣.	Air filter housing/pipes/hoses (petrol)	Check/clear	. <del>–</del> 1	Brake hydraulic fluid	D
Additional at 60,000 mile service		•	Air filter housing/pipes/hoses (diesel)	Check/clear	:	•	Renew
	Check/report	71	Diesel fuel filter	Renew		Additional every 10 years	
eering/suspension							
	Check/report		Crankcase ventilation (petrol)	Check/clean		SRS	Visual check

Published by Autodata Limited, Priors Way, Maidenhead, Berkshire, SL6 2HP