

TRANSMISSION SERVICING - M/T

1995 Volvo 850

Manual Transmission Servicing

850

MODEL IDENTIFICATION

MANUAL TRANSMISSION APPLICATIONS

Vehicle Model	Transmission Model
850	M56L (5-Speed)

LUBRICATION

SERVICE INTERVALS

Check fluid every 7500 miles.

CHECKING FLUID LEVEL

Fluid level should be at bottom of fill hole. Use socket to remove plug. Clean strainer and magnet with solvent. Replace filter and tighten plug

RECOMMENDED FLUID

Use Type "F" ATF or Volvo Synthetic Oil (11614237).

FLUID CAPACITIES

TRANSMISSION REFILL CAPACITIES

Application	Qts. (L)
M56L	2.2 (2.1)

ADJUSTMENTS

LINKAGE

No external linkage adjustment is required.