Header text

Roof, windshield/rear window frame

Roof, alignment chart

Obs! The illustrations in this service information are used for different model years and/or models. Some variation may occur. However, the essential information in the illustrations is always correct.

Dimensions

Explanation of dimensions

The dimensions in the table are listed as follows:

Symbol number 1 means that the measurement is taken from the center.

Symbol number 2 means that the measurement is taken from an edge.

1 ⊙


2 [┼

3

R8101811




1





Symbol number 3 means that the measurement is taken from a cut mark.


Measurements are taken from the bottom of the recess, see illustration.


If only one measuring point symbol is displayed, the symbol applies to both measuring points. Otherwise the symbols are shown on each side of the dimension in the illustration.















1



Windscreen frame, alignment chart

Obs! The illustrations in this service information are used for different model years and/or models. Some variation may occur. However, the essential information in the illustrations is always correct.

Dimensions

Explanation of dimensions

The dimensions in the table are listed as follows:


Symbol number 1 means that the measurement is taken from the center.

Symbol number 2 means that the measurement is taken from an edge.

1 💿

2 [┼

R8101811



Symbol number 3 means that the measurement is taken from a cut mark.

Measurements are taken from the bottom of the recess, see illustration.

If only one measuring point symbol is displayed, the symbol applies to both measuring points. Otherwise the symbols are shown on each side of the dimension in the illustration.

