

## Weatherstrip, rear roof panel, preplacing

**Obs!** The illustrations in this service information are used for different model years and/or models. Some variation may occur. However, the essential information in the illustrations is always correct.

### Removing

1


#### Removing seal strip, side

Pull loose the seal strip. Start at the top edge of the strip.

### Installing

2


Fasten the butyl tape at (3), part number 1161782.



IMG-

235699

3



IMG-

235741

Apply soapy water on the strip.

Install the seal acc. to the figure.


### Removing

4

1

### Removing seal strip, rear

Remove the nuts, 2 pcs. M8. Tightening torque acc. to: VCC-149646-1, Tightening torque.




IMG-

235747

5


### Installing



IMG-

235749

6



IMG-

235752