

Weatherstrip, roof bow/A-posts, replacing

Obs! The illustrations in this service information are used for different model years and/or models. Some variation may occur. However, the essential information in the illustrations is always correct.

Removing


1

Remove the panel on the upper windshield member acc. to: VCC-255601-1, Panel, upper windshield member, replacing.

2

Remove the screws, 14 pcs. M6.

Mark the locks' (1) placement, 2 pcs.



IMG-

235360

Pull loose the strip.



IMG-

235423

Installing

3


Obs! For tightening torques, see: VCC-149646-1, Tightening torque.

Apply soapy water on the sealing strip and pull it in.



IMG-


235431



IMG-

235432

Install the screws, 14 pcs. M6.



IMG-

235435


4

5

Install the panel on the upper windshield member acc. to: VCC-255601-1, Panel, upper windshield member, replacing.

Finishing

6



Inject lots of sealant (2), part number 116 1235.

Run down the roof and wipe off excess sealant that the roof forces out.

235442

IMG-