

FUSES & CIRCUIT BREAKERS

1995 Volvo 850

1993-96 FUSES & CIRCUIT BREAKERS
Volvo


1993-96 850 Sedan
1994-96 850 Turbo Sedan
1995-96 850 T-5R Turbo Sedan
1994-96 850 Wagon
1994-96 850 Sportswagon
1995-96 850 T-5R Turbo Sportswagon

IDENTIFICATION

FUSE PANEL LOCATION

The fuse panel is located in the engine compartment. A label on the inside of the cover lists the fuse amperage and circuits protected.

FUSE PANEL IDENTIFICATION



93C45544

Fig. 1: Fuse Panel Identification
Courtesy of Volvo Cars of North America.

WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

- * 1 - 15 Amp
Fuel Injection, Distributor Ignition, Automatic Gearbox
- * 2 - 15 Amp
Fuel Pump, Alarm System
- * 3 - 10 Amp
Courtesy Lights, Oil Level Sensor
- * 4 - Not Used (1993-95)
- * 4 - 10 Amp (1996)
Electronic Start Inhibitor (Immobilizer)
- * 5 - 30 Amp
ECC Blower (Speed 4)
- * 6 - 25 Amp
Central Locking System, Alarm
- * 7 - 15 Amp
Audio System (Amplifier)


- * 8 - 25 Amp (1993-95)
Power Antenna, Trailer Connector
- * 8 - 40 Amp (1996)
Electronic Start Inhibitor (Immobilizer)
- * 9 - 30 Amp
ABS, Traction Control System
- * 10 - Not Used (1993-95)
- * 10 - 15 Amp (1996)
Heated Rear Seat (If Equipped)
- * 11 - 30 Amp
Heated Rear Window & Side Mirrors
- * 12 - 10 Amp
Brake Lights
- * 13 - 15 Amp
Hazard Flashers, Headlight Flashers, Alarm
- * 14 - 30 Amp
ABS, Traction Control System
- * 15 - 10 Amp (1993-95)
Audio System, Courtesy Lights, Door Open Light, Trunk Light,
Glove Box Light, Remote Control Central Locking System,
Oil Level Sensor, Seat Belt Reminder
- * 15 - 10 Amp (1996)
Audio System, Courtesy Lights, Door Open Light, Trunk Light,
Glove Box Light, Remote Control Central Locking System,
Oil Level Sensor, Seat Belt Reminder, Data Link Connector
- * 16 - 30 Amp (1993-95)
Accessories
- * 16 - 30 Amp (1996)
Power Antenna, Trailer Connector, Accessories
- * 17 - 10 Amp
Key Reminder
- * 18 - 25 Amp (1993-95)
Heated Front Seats, Power Mirrors
- * 18 - 15 Amp (1996)
Front Fog Lamps
- * 19 - 15 Amp
Left High Beam Headlight
- * 20 - 15 Amp
Right High Beam Headlight, High Beam Indicator
- * 21 - 15 Amp
Left Low Beam Headlight
- * 22 - 15 Amp
Right Low Beam Headlight
- * 23 - 10 Amp
Left Parking Light, License Light
- * 24 - 10 Amp
Right Parking Light, Bulb Failure Warning Sensor
- * 25 - 10 Amp
Rear Fog Lamps, Fog Lamp Indicator
- * 26 - Not Used (1993-95)
- * 26 - 25 Amp (1996)
Heated Front Seats, Power Mirrors
- * 27 - 15 Amp
Back-Up Lights, Turn Signals
- * 28 - 10 Amp
Cruise Control, Heated Rear Window, Seat Belt Reminder Light,
Shiftlock, Bulb Failure Warning Sensor, Heated Rear Seat
- * 29 - 15 Amp
ABS, Traction Control System
- * 30 - 10 Amp
Cigarette Lighter
- * 31 - 25 Amp
ECC, ECC Blower (Speeds 1-3)

- * 32 - 10 Amp
Audio System, Remote Controlled Central Locking System
- * 33 - 15 Amp (1993-95)
Power Seats, OBD Test Socket, Tailgate Washer/Wipe (Wagon)
- * 33 - 15 Amp (1996)
Power Seats, Tailgate Washer/Wipe (Wagon)
- * 34 - 25 Amp
Windshield Wiper/Washer, Horn, Headlight Washer/Wiper
- * 35 - 10 Amp
Instrument Lights, Sun Roof, Traction Control System
- * 36 - Not Used
- * 37 - Circuit Breaker
Power Windows, Power Sun Roof
- * 38 - Not Used
- * 39 - Circuit Breaker
Drivers Power Seat
- * 40 - Circuit Breaker
Passengers Power Seat

RELAY PANEL LOCATION

The relay panel is located at the left corner of the instrument panel.

RELAY PANEL IDENTIFICATION



50B11925




Fig. 2: Relay Panel Identification
Courtesy of Volvo Cars of North America.

- * A - Control Module, Cruise Control
- * B - Fuel Pump Relay

- * C - Main Headlight Relay with Bulb Malfunction Indicator
- * D - Overload Relay (+X Supply)
- * E - Overload Relay (+15 Supply)
- * F - Overload Relay (+X Supply)
- * G - Oil Level Sensor Control Module (or Lamp Monitor)
(1993-95), Fog Lamp Relay (1996)
- * H - Deadlock Setting Relay
- * I - Intermittent Windshield Wiper Relay
- * J - Intermittent Wiper Relay (Rear Tailgate - Wagon)
- * K - Central Lock and Delayed Inside Lighting Relay
- * L - Speed Warning Relay
- * M - Heated Rear Window and Door Mirror Relay
- * N - Not Used
- * O - Anti-Theft Alarm Relay
- * P - Seat Belt Reminder/Key Warning Relay
- * Q - Parking Position Lock (1993-95)
Front Fog Lamp Relay (Bridged if not equipped) (1996)
- * R - Heated Rear Seat Relay
- * S - Not Used