

Alphabetical index

Check point	designation
Air filter, replace	D1
Anti-corrosion treatment/paintwork, check	C6
Automatic gearbox, drain oil	B3
Automatic gearbox, fill oil	D5
Automatic gearshift control, check	A1
Auxiliary unit belt (B 5204/5252/5254), replace	D10
Auxiliary unit belts (B 16/18/20, B 200/230, B 204/234), check/adjust	D9
Battery, check level/attachment	D7
Brake/fuel pipes, check for leakage/damage	B10
Brake hoses, check for leakage/damage	B9
Brake linings (discs), check	B8
Camshaft belt (B 200-230), check-tighten	D13
Camshaft belt (B 200/230, B 204/234, B 5204/5252/5254), replace	D11
Camshaft belt and auxiliary unit belt (B 16/18/20, B 6304), replace	D12
Camshaft belt, pump belt, idler pulley (D 24), replace	D14
Clutch (240), check/adjust	B4
Clutch (400), check/adjust	A5
CO-idling, check/adjust	D18
Crankcase ventilation, clean	A7
Distributor (240), lubricate	D8
Doors, bonnet, lubricate hinges, bonnet lock	D19
Driveshafts (400, 800), check for play/wear	B5
Driveshafts (400, 800), check rubber gaiters	B6
Drum brakes rear (400), check	C7
EGR system (B 230 FD and D 24 T Austria), clean	D17
EGR system (D 24 T Austria and others), check function	D16
Engine, check for leakage (from above)	A8
Engine, drain oil and replace oil filter	B2
Engine, fill oil	D4
Engine/gearbox, check for leakage (from underneath)	B1
Exhaust system, check condition/tightness/anchorage	B15
Final drive, check for leakage/oil level	B14
Fluid levels, engine compartment, check/adjust	D6
Fuel filter - diesel, drain condensate	B12
Fuel filter - diesel, replace	B13
Fuel filter - petrol, replace	B11
Kickdown wire, check/adjust	A6
Outside lighting, check	A3
Parking brake, check/adjust	A2
Power antenna, clean	D21
Propeller shaft, support bearing, universal joints	C3
Rear suspension, check-tighten	C4
Rear suspension, check wear	C5
Service reminder (850), reset	D20
Spark plugs, replace	D2
Steering system/front suspension, check-tighten	C1
Steering system/front suspension, check for wear	C2
System diagnosis (FENIX engine diagnosis - 400)	D15

Tyres, check	B7
Valves, check/adjust	D3
Wipers/washers on windscreen and headlamps, check/adjust	A4