

Service Bulletin

Tool for
disassembling
crankshaft pulley

Tool No.	Description	Used on
SVO 2279	Puller for crankshaft pulley	B4B, B14 and B16 engines

Description of work

1. Fit nut on crankshaft.
2. Fit puller on pulley as shown in illustration. Check that both of the claws are correctly seated in the pulley groove before the yoke bolt is tightened.
3. Pull off the pulley by tightening the centre bolt.

