## 2002 MODEL YEAR SERVICE PROGRAMME

Model	Model Years
S60 Diesel	2002 →
V70 Diesel	2002 →
S80 Diesel	2002 →

WNERS NAME		
EHICLE REG NO.		-
ILEAGE		_
Key: Checked/Completed  Needs Attention	Adjusted Not Applicable	

Annual service or 12,000 miles		Additional at 60,000 miles or 5 ye	ars	Additional at 156,000 miles or 13	years
VEHICLE ON FLOOR		Steering/suspension	Check/report	Steering/suspension	Check/report
Wash/wipe system	Check/report [	Exhaust system/mountings	Check/report	Exhaust system/mountings	Check/report
Exterior lighting system	Check/report	Front wheel bearings		Front wheel bearings	Check/report
VEHICLE FULLY RAISED				Additional at 168,000 miles or 14	vears
Engine oil leaks	Check/report	Additional at 72,000 miles or 6 years		Steering/suspension	Check/report
Engine oil	Drain/refill 🔲	Steering/suspension	Check/report	Exhaust system/mountings	Check/report
Engine oil filter	Renew 🔲	Exhaust system/mountings	Check/report	Front wheel bearings	Check/report
Clutch hydraulic system	Check/report	Front wheel bearings	Check/report	Diesel fuel filter	Renew
Gearbox oil leaks	Check/report	Diesel fuel filter	Renew 🔲		
Gearbox oil (only in event of leakage)	Check/top-up	Air filter	Renew 🔲	Additional at 180,000 miles or 15	
Auto transmission oil leaks	Check/report	Air filter housing/pipes/hoses	Check/clean	Steering/suspension	Check/report
Auto transmission inhibitor switch	Check 🔲	Additional at 84,000 miles or 7 y	pars	Exhaust system/mountings	Check/report
Driveshafts	Check/report	Steering/suspension	Check/report	Front wheel bearings	Check/report
Brake pipes/hoses condition	Check/report	Exhaust system/mountings	Check/report	Air filter	Renew 🗌
Fuel system leakage	Check/report	Front wheel bearings	Check/report	Air filter housing/pipes/hoses	Check/clean
VEHICLE HALF RAISED	,	From wheel bearings	Checkreport [	Additional at 192,000 miles or 1	S years
Brake pads/discs	Check/report	Additional at 96,000 miles or 8 y	ears	Auto transmission oil (adverse cond	itions) Drain/refill 🔲
Handbrake cables/linkages	Check/report	Auto transmission oil (adverse condi	tions) Drain/refill [	Steering/suspension	Check/report
Handbrake	Adjust 🔲	Steering/suspension	Check/report	Exhaust system/mountings	Check/report
Brake hydraulic system	Check/report	Exhaust system/mountings	Check/report	Front wheel bearings	Check/report
Tyre condition	Check/report	Front wheel bearings	Check/report	Diesel fuel filter	Renew 🔲
Tyre pressures	Check/adjust	Diesel fuel filter	Renew 🔲	Timing belt - apply decal	Renew 🔲
UNDER BONNET OPERATIONS	, , , , , , , , , , , , , , , , , , , ,	Timing belt - apply decal	Renew 🗀	Timing belt tensioner	Renew 🔲
Fluid reservoir levels	Check/top-up	Timing belt tensioner	Renew 🔲	Auxiliary drive belt - apply decal	Renew 🔲
Coolant level/anti-freeze strength	Check/adjust	Auxiliary drive belt - apply decal	Renew 🗀	Additional at 204,000 miles or 1	7 years
Coolant hoses	Check/report			Steering/suspension	Check/report
Auto transmission level		Additional at 108,000 miles or 9		Exhaust system/mountings	Check/report
(only in event of leakage)	Check/top-up	Steering/suspension	Check/report	Front wheel bearings	Check/report
Diesel fuel filter	Drain 🗌	Exhaust system/mountings	Check/report	Additional at 216,000 miles or 1	8 vears
Pollen filter (if fitted)	Renew [_]	Front wheel bearings	Check/report	Steering/suspension	Check/report
FINAL ITEMS CHECK	a ,	Air filter	Renew [	1	Check/report
1	Clean/re-grease	Air filter housing/pipes/hoses	Check/clean 🔲	Exhaust system/mountings Front wheel bearings	Check/report
Battery electrolyte level	Check/top-up	Additional at 120,000 miles or 1	0 years	Diesel fuel filter	Renew
Battery security	Check 📙	Steering/suspension	Check/report	Air filter	Renew [
Check all systems for fault codes (DTC		Exhaust system/mountings	Check/report		Check/clean
"WHIPS" - position of indicator pin	Check	Front wheel bearings	Check/report	Air filter housing/pipes/hoses	_
Service reminder lamp (SRL)	Reset [	Diesel fuel filter	Renew	Additional at 228,000 miles or	
Doors/bonnet	Lubricate	Bross radi mila	, tonou	Steering/suspension	Check/report
Detachable tow bar	Lubricate [_]	Additional at 132,000 miles or 1	1 years	Exhaust system/mountings	Check/report
ROAD TEST VEHICLE		Steering/suspension	Check/report <a>D</a>	Front wheel bearings	Check/report
As per separate sheet	Check/report	Exhaust system/mountings	Check/report	Additional at 240,000 miles or	20 years
Additional at 24,000 miles or 2 years	ears	Front wheel bearings	Check/report	Auto transmission oil (adverse con	ditions) Drain/refill
Diesel fuel filter	Renew	Additional at 144,000 miles or	2 vears	Steering/suspension	Check/report
		Auto transmission oil (adverse con	1	Exhaust system/mountings	Check/report
Additional at 36,000 miles or 3 years		Steering/suspension	Check/report	Front wheel bearings	Check/report
Air filter	Renew	Exhaust system/mountings	Check/report	. I Diesel tuel tilter	Renew [
Air filter housing/pipes/hoses	Check/clean	Front wheel bearings	Check/report	Additional ayens 2 years	
Additional at 48,000 miles or 4 years	nare	Diesel fuel filter	Renew _	Proko budraulio fluid	Renew [
	Gal S				
Auto transmission oil (adverse condit		Air filter			
Auto transmission oil (adverse condit Diesel fuel filter		Air filter	Renew Check/clear	Additional every 10 years	Visual check

specified above has been carried out.

Date:

R.O. NO.

This service is part of the maintenance programme put together specifically for your Volvo. It has been carefully carried out by a Volvo trained technician who has fitted genuine Velvo parts. Only your official Volvo Dealer has the necessary special tools and service information required to care for your Volvo and provide you with safe and reliable motoring.

Signed: